
User Guide


WARNING:

Be careful to open it becsue of the net fold in tight tension !
The net pop-up quickly when take off tie band .


A set included:



Installation



1.Pull each side of the Chip Shot base apart to form a tringle shape (Fig. 1). The net should now be standing upright on its own without any slack in the bottom straps on each side.



2.Lay each pole along the bottom straps. Insert poles into the strap sleeve at each end to create a sturdy base.(Fig. 2)




3. Choose the direction for your target by attaching it with the provided velcro tape.


4. If used on grass or sand,the goal can be secured with ground stakes.




Folding Instruction



1.Remove the rods from the bottom strap and fold each rod over. Place the net parallel and grab the two corners at each end (3 layers)




2.Fold the 2 corners towards eacn other.



3.Twist the 2 corners to form two clrcles,then fold them over each other.



4.Overlap them with the circle at the other side.



5. Please fold the net neatly and store it in a bag when not in use.